

INSTALLATION INSTRUCTIONS

Arms may be attached to vertical C-section columns by using one of three mounting posts (A) or to top of bench using bench mount post (B). Any of the components shown below may be combined to assemble most usable configuration.

- Attach desired mounting post to column by sliding down from top (Fig. 1). Be certain clamping bar is to inside of column. Position at desired height and securely clamp in place. If bench top mounting is desired, bolt bench mount post in desired location.
- 2. Loosen, do not remove, knob(s) on arms and attachments. Make certain that black lubrication sheet is rolled inside round tube. Slide tube(s) over post(s), assembling unit as desired (Fig 2).
- 3. Position arms and accessories as desired. Tighten knobs to reduce or prevent unwanted movement.

